

WARNING Failure to observe the following directions could

Do not leave the product near infants, children, or pets.

and/or their saliva may get into the product, causing

There is a risk of them swallowing small components.

Do not spray water or wax directly onto the product while

Doing so may cause fire, electric shock, or malfunction.

If smoke or an unusual smell is emitted from the power cord,

result in death or serious injury:

an explosion due to a short circuit

detach the nower cord immediately

Contact the service center or your distributor.

Failure to do so may cause excessive heat and fire.

Plug in the power cord firmly so that it cannot easily be

Failure to do so may cause explosion, fire, or malfunction.

Doing so may cause external deformation of the product or fire.

Use the product and peripherals in a well-ventilated location.

Keep the terminals of the power cord clean.

cleaning the inside of the car

Use the correct input voltage.

Failure to do so may cause fire.

Do not cover the product with any material.

disconnected.



# Layout:

- 1 Type-C Power Supply Port
- 2 TF Card Slot
- 3 Lens
- 4 Reset Button
- 5 Power Button 6 - WiFi Indicator
- 7 Recording Indicatorx
- 8 Bracket

## **Product Parameter:**

Video Resolution- FHD 1080p Wi-Fi- Supports 2.4G Wi-Fi Loop Recording Video Format- H.264 TS Storage- SD Card Up To 128GB (C10 or Above)

## Package Including:

Host camera X1pc Car charger X1pc User manual X1pc Color box X1pc Memory card 64GB

# CAUTION Failure to observe the following directions could result in injury or property damage:

- Do not spray cleaning products directly onto the product. Doing so may cause discoloration, cracks, or malfunction.
- If the product is used outside the optimal temperature range, performance can decline or malfunctions may occur.
- Make sure that the product is installed properly. If installed incorrectly, vibrations may cause the product to fall, and may cause physical injury.
- sunlight, or when recording at night without lighting the quality of recorded video may deteriorate.
- accident, video may not be recorded.
- Excessively tinted windshield glass can distort the recorded
- temperature and cause burns.
- after prolonged use. microSD cards may not record video correctly after extended use, so check the microSD card's recording capability periodically and replace as necessary

Do not remove the microSD card while the microSD card is saving or reading data.

The data can be damaged or malfunctions may occur.

### WiFi Connect & APP:

- 1. Wi-Fi function allows to transmit recordings from the dashcam directly to the mobile device and to view them from there.
- 2. Download "VIIDURE" APP for the Android or iOS from Google Play or Apple store. Or scan the following QR code to install:



- 3. Turn on the camera and start to connect with the Wifi function
- 4. Search the Wifi name and enter password to use the APP: Wifi name: AiRD D100 XXXX Passwords: 1234567890

# Video/Photo Playback:

1. Playback by App:

Please connect with Wifi and open the mobile APP to find the Video and Photos to Playback.

2. Playback by Computer:

Please unplug the SD card and find a memory card reader, then you can connect with the computer and see the video and photo files, which can be freely playback and download.


## **Memory Card Instructions**

- A memory card (sold separately) must be installed in the dashcam before use.
- The dash cam supports standard MicroSD cards. Please use memory cards with the minimum capacity of 32 GB and rating of U1(UHS-1) or above.
- the format supported by the dash cam. When inserting the memory card for the first time, please format it in the dash cam before use. Formatting the memory card will delete all files on the card. Please back up important data to another device before it. The memory card may be come damaged or deteriorated after repeated cycles of overwriting, and this may affect its ability to save video and image files. If this occurs, immediately replace it with a new memory card
- Inferior memory cards may have issues such as actual reading / writing that does not match the stated storage capacity. We shall not be held liable for lost or damaged videos caused by the use of a low-quality memory card.
- it is recommended to format the memory card in the dash cam every two weeks.
- Do not insert or remove a memory card while the dash cam is turned on.

online guide to ensure correct and safe use

- This dash cam is intended to assist drivers with the purpose of recording the environment outside the vehicle. The dash cam does not guarantee the user's driving safety. We shall not be held liable for any accident, damage, or loss of information caused by operating the d a s h cam while driving.
- Due to differences in vehicle conditions, driving style, driving environment, etc., some functions may not work properly. A power failure, usage in environments outside t he normal operating temperature or humidity range, a collision, or a damaged memory card may cause the dash cam to function abnormally. There is no guarantee that this dash cam will function normally under all circumstances. Videos recorded by this dashcam are for reference only

## The Best Installation Position:



# **Button Operating:**

Button	Status	Function	]
	Power Off	Short press to power on	]
Power/OK	Recording mode	Short press to stop/start recording	]
	Any status	Long press to power off/on	

# Indicator Operating:

or power cord

following measures

following two conditions

cause damage to the dash cam.

operate the equipment

- Reorient or relocate the receiving antenna

(1) this device may not cause harmful interference

Indicator	Function	Recording
Blue	Video recording	When camera is working and keep recording, the blue light will keep blinking; when stop recording, the light will keep staying the blue light.
Red ===	Wifi	After connect with WIFI and Wifi is working, the red light will keep blinking.

• Please use the included car charger, power cord, and other accessories in

order to avoid product failure due to non-conformance. We shall not be held

liable for any loss or damage caused by the use of a non-genuine car charger

Please keep this dash cam away from any strong magnetic fields, as they may

Changes or modifications not expressly approved by the party

This equipment has been tested and found to comply with the limits for a

Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are

residential installation. This equipment generates, uses and can radiate radio

If this equipment does cause harmful interference to radio or television reception,

- Connect the equipment into an outlet on a circuit different from that to which

This device complies with Part 15 of the FCC Rules. Operation is subject to the

(2) this device must accept any interference received, including interference

This equipment complies with FCC radiation exposure limits set forth for an

uncontrolled environment. This equipment should be installed and operated

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the

designed to provide reasonable protection against harmful interference in a

frequency energy and, if not installed and used in accordance with the

instructions, may cause harmful interference to radio communications.

However, there is no quarantee that interference will not occur in a

- Increase the separation between the equipment and receiver

- Consult the dealer or an experienced radio/TV technician for help.

responsible for compliance could void the user's authority to

• Do not use this dash cam in environments with temperatures over 60°C or

• Please only use this dash cam within the scope permitted by law.

### Important Safety Information:

For user safety and to avoid property damage, read through this manual and follow these safety instructions to use the product

DANGER Failure to observe the following directions could result in death or property damage:

- Do not disassemble, repair, or modify the product yourself. Doing so may cause fire, electric shock, or malfunction. For internal inspection and repair, contact the service center.
- If any foreign matter gets inside the product, detach the power cord immediately Contact the service center for repair.
- Do not adjust the product while driving. Doing so may cause an accident. Stop or park your car in a safe place before installing and setting up the product
- Do not install the product in a location where the product can interfere with the driver's field of vision Doing so may cause an accident.
- Do not use a damaged or modified power cord. Only use the cords provided by the manufacturer. Damaged or modified power cords may cause an explosion, fire, or malfunction. Do not operate the product with wet hands. Doing so may cause electric shock.
- Do not install the product in an environment with high humidity, or combustible gases or liquids. Doing so may cause an explosion and/or fire.

with a minimum distance of 20 cm between the radiator & your body. This

transmitter must not be co-located or operating in conjunction with any other antenna or transmitter

### Regulatory Compliance Information WEEE Information



All products bearing this symbol are waste electrical and electronic equipment (WEEE as in directive 2012/19/EU) which should not be mixed with unsorted household waste. Instead, you should protect human health and the environment by handing over your waste equipment to a designated collection point for the recycling of

waste electrical and electronic equipment, appointed by the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences to the environment and human health. Please contact the installer or local authorities for more information about the location as well as terms and conditions of such collection points.

# EU Declaration of Conformity



The manufacturer here by, declares that the equipment is in compliance with the applicable Directives and European Norms, and amendments. The full text of the EU declaration of conformity is available at the following internet address; https://aird.live

### Safety Information Caution

Battery abuse or mishandling can cause overheat, liquid leakage, or an explosion. To avoid possible injury, do the following:

- . Do not open, disassemble, or service any battery
- Do not attempt to replace the internal rechargeable lithium batteries.
- . Do not crush or nuncture the battery
- . Do n o t short-circuit t h e battery, or expose it to water or other liquids.
- Keep the battery away from children
- Keep t h e battery away from fire.
- Do not leave the battery in a n extremely high-temperature environment or an
- extremely low air pressure environment · Stop using the battery if it is damaged, or if you notice any discharge or the
- buildup of foreign materials on the battery leads. We recommend that the batteries be charged about once every three months to prevent overcharge. • Do not put the battery in trash that is disposed of in landfils. When disposing of the battery, comply with local laws or regulators. Do not attempt to replace the internal rechargeable lithium batteries.

- When entering or exiting a tunnel, when directly facing into bright
- If the product is damaged or the power supply is cut due to an
- video or cause recorded video to be indistinct.
- Prolonged use of the product can increase the interior
- microSD cards are consumables, so replace microSD cards

- The default file partition format of the memory card may be inconsistent with
- Please use a high-quality memory card purchased from a reputable vendor. speeds that do not match the stated speeds, and an actual storage capacity
- In order to avoid reading and writing speeds decreasing after prolonged use,

Before using this dash cam, please read all the precautions and the